



General Purpose Corded Handheld Linear Imager Bar Code Reader

The QuickScan reader series is Datalogic Scanning's value line of general purpose handheld data collection products. The QuickScan I QD2100 linear imaging reader is an entry level product that is perfect for use in retail and office environments plus activities associated with couriers and postal services.

The QD2100 is small, lightweight and its ergonomic design is comfortable to use during daily operations. It offers snappy reading performance especially on hard to read bar codes and is capable of reading a wide range of symbologies including the majority of 1D codes plus GS1 DataBar™ linear codes. The QD2100 reader features Datalogic's exclusive patented 'Green Spot' for good read feedback directly on the code. When in Stand Mode, the Green Spot remains on to show the operator where to position the code for quick and intuitive reading.

Like the QuickScan L reader, the QD2100 has been designed with durability in mind. One of the most vulnerable features

of any scanner is damage to the scan window. When such incidents happen, the scanner may have to be replaced. The QD2100 was specifically designed so that a replacement window pack can be ordered to replace damaged or scratched windows without having to send the scanner away for repairs. This helps to reduce the total cost of ownership during the life of the scanner and helps to ensure that it is always available for use.

The QD2100 is available with two multi-interface options: RS-232 / IBM 46XX / USB and RS-232 / USB / Keyboard Wedge / Wand and includes various packaging options so that it can be ordered as the scanner only or as a kit equipped with a scanner, cable and stand to facilitate hand-free reading options. The Datalogic Aladdin™ configuration program provides user-friendly features that simplify the start-up procedure, even for inexperienced users.



Features

- Datalogic Green Spot for good read feedback
- User replaceable scan window
- Two multi-interface options support the most popular interface combinations
- Supports GS1 DataBar™ codes
- Remote host download functions (Model QD2110)
- Water and Particulate Sealing Rating: IP42
- Drop resistance to 1.5 m / 5.0 ft



Specifications

DECODING CAPABILITY

1D / LINEAR CODES

Autodiscriminates all standard 1D codes including GS1 DataBar™ linear codes

POSTAL CODES
STACKED CODES

China Post
GS1 DataBar Expanded Stacked; GS1 DataBar Stacked; GS1 DataBar Stacked Omnidirectional

ELECTRICAL

CURRENT

Operating (Typical): 340 mA @ 5 VDC

Standby/Idle (Typical): 190 mA @ 5 VDC

QD2110: 4 -14 VDC; QD2130: 5 VDC +/- 10%

INPUT VOLTAGE

ENVIRONMENTAL

AMBIENT LIGHT

100,000 lux

DROP RESISTANCE

Withstands repeated drops from 1.5 m / 5.0 ft onto a concrete surface

ESD PROTECTION (AIR DISCHARGE)

20 kV

HUMIDITY (NON-CONDENSING)

5 - 95%

PARTICULATE AND WATER SEALING

IP42

TEMPERATURE

Operating: 0 to 50 °C / 32 to 122 °F

Storage/Transport: -40 to 70 °C / -40 to 158 °F

INTERFACES

RS-232 / IBM 46XX / USB Multi-Interface: QD2110

RS-232 / USB / Keyboard Wedge / Wand Multi-Interface: QD2130

PHYSICAL CHARACTERISTICS

COLORS AVAILABLE

Black; White

DIMENSIONS

17.0 x 7.1 x 6.6 cm / 6.7 x 2.8 x 2.6 in

WEIGHT

121.9 g / 4.3 oz

READING PERFORMANCE

LIGHT SOURCE

Red LED 610-650 nm

PRINT CONTRAST RATIO (MINIMUM)

15%

READ RATE (MAXIMUM)

270 reads/sec.

READING ANGLE

Pitch: +/- 65°; Roll (Tilt): +/- 45°; Skew (Yaw): +/- 65°

READING INDICATORS

Beeper (Adjustable Tone); Datalogic 'Green Spot' Good Read Feedback; Good Read LED

RESOLUTION (MAXIMUM)

0.102 mm / 4 mils

READING RANGES

TYPICAL DEPTH OF FIELD

Minimum distance determined by symbol length and scan angle. Printing resolution, contrast, and ambient light dependent.

4 mils: 2.0 to 11.0 cm / 0.8 to 4.3 in

5 mils: 1.5 to 15.0 cm / 0.6 to 6.0 in

7.5 mils: 0.8 to 25.0 cm / 0.3 to 10.0 in

10 mils: 0.8 to 38.0 cm / 0.3 to 15.0 in

13 mils: 1.9 to 45.0 cm / 0.7 to 18.0 in

20 mils: 2.5 to 65.0 cm / 1.0 to 26.0 in

SAFETY & REGULATORY

AGENCY APPROVALS

The product meets necessary safety and regulatory approvals for its intended use.

The Quick Reference Guide for this product can be referred to for a complete list of certifications.

ENVIRONMENTAL COMPLIANCE

Complies to China RoHS; Complies to EU RoHS

LED CLASSIFICATION

IEC 60825-1 Class 1 LED Product

UTILITIES

DATALOGIC ALADDIN™

Datalogic Aladdin configuration program is available for download at no charge

REMOTE HOST DOWNLOAD

Lowers service costs and improves operations: QD2110

WARRANTY

5-Year Factory Warranty



Miscellaneous

- 11-0318 Replacement Windows, 5-Pack



Mounts/Stands

- STD-QD20-BK Gooseneck Stand, Black
- STD-QD20-WH Gooseneck Stand, White

